



Separating the bearing unit from the column from Supertechno50+ from series no. 656




STEP 1



Lift the beam unit


STEP 2



This is the key
and the keyway.


Never loosen
the red screw!

STEP 3



Unscrew
11xM8 around
the upper part
of the column.
Lift the bearing
unit out.

STEP 4



Screw 8xM12 to
secure the adapter

STEP 5